





**Keychain Remotes** - - Keychain remotes allow you to turn on and off your security alarm system with one touch of a button. Additionally, keychain remotes can be programmed as panic buttons to be used in emergency situations.



**Door/Window Contacts** - Door and Window contacts alert the security alarm system when your doors or windows are opened.



**Motion Detectors** - Motion Detectors alert your home security alarm system when movement is detected. Motion Detectors can cover large areas and cover multiple points of entry. New motions from Honeywell are pet friendly up to a 80lb pet.



**Glass Break Detector** - Glass Break Detectors will alert your home security alarm if glass is broken near the detector.



**Smoke Detector** - Smoke Detectors help to protect you and your home incase of fire.



**Heat Detector** - Heat Detectors will alert you if temperature levels reach dangerous levels.



**Carbon Monoxide Detector** - Carbon Monoxide Detectors will detect dangerous levels of carbon monoxide in the vicinity of the carbon monoxide detector.



**Interior Siren** - The Interior Siren is a loud 110 decibels and is meant to scare off any intruder.



**Exterior Siren** -The Exterior Siren not only scares off would be intruders but will also alert your neighbors of a possible burglary event.



**Transformer**- Transformer provides power to your home security alarm.



**Back-up Battery** - The Back-up Battery powers your home security alarm system for up to 24-hours in case of power outage.



**Water Sensor** - A Water Sensor will sense moisture levels and alert our central monitoring station of unusual moisture levels.



**Temperature Sensor** - A Temperature Sensor can be set to send an alert through your home security alarm if temperature levels go too high or too low.

**For all of your home security alarm needs!**